

| | | | | | |
|---------|-------------|----------|-------------|----------|----------|
| vol 1 | push 31 sv2 | a 30 sv2 | b29 sv2 | | |
| switch1 | 32 sv2 | | | | |
| nav | push 27 sv2 | a 23 sv2 | b 24 sv2 | c 25 sv2 | d 26 sv2 |
| hdg | push 28 sv2 | a 22 sv2 | b 21 sv2 | | |
| AP | 3 SV3 | | | | |
| YD | 1 SV3 | | | | |
| FD | 4 SV3 | | | | |
| HDG | 2 SV3 | | | | |
| NAV | 6 SV3 | | | | |
| APR | 5 SV3 | | | | |
| ALT | 8 SV3 | | | | |
| VNV | 7 SV3 | | | | |
| VS | 10 SV3 | | | | |
| NOSE UP | 9 SV3 | | | | |
| FLC | 16 SV3 | | | | |
| NOSE DN | 18 SV3 | | | | |
| ALT | PUSH 13 SV2 | A 18 SV2 | B 17 SV2 | C 16 SV2 | D 15 SV2 |
| P1 | 11 SV2 | | | | |
| P2 | 9 SV2 | | | | |
| P3 | 14 SV2 | | | | |
| P4 | 12 SV2 | | | | |
| P5 | 10 SV2 | | | | |
| P6 | 7 SV2 | | | | |
| P7 | 8 SV2 | | | | |
| P8 | 4 SV2 | | | | |
| P9 | 2 SV2 | | | | |
| P10 | 5 SV2 | | | | |
| P11 | 3 SV2 | | | | |
| P12 | 1 SV2 | | | | |
| FMS | PUSH 2 SV4 | A 31 SV4 | B 32 SV4 | C 30 SV4 | D 29 SV4 |
| CLR | 6 SV4 | | | | |
| ENT | 4 SV4 | | | | |
| FLP | 1 SV4 | | | | |
| PROC | 3 SV4 | | | | |
| FLECHE | 10 SV4 | | | | |
| MENU | 8 SV4 | | | | |
| JOY | G 28 SV4 | D 25 SV4 | H 22 SV4 | B 24 SV4 | |
| JOY | A 23 SV4 | B 27 SV4 | PUSH 26 SV4 | | |
| CRS | PUSH 21 SV4 | A 17 SV4 | B 18 SV4 | C 19 SV4 | D 20 SV4 |

| | | | | | |
|-----------|------------|------------|----------|----------|----------|
| COM | PUSH 5 SV4 | A 16 SV4 | B 15 SV4 | C 13 SV4 | D 14 SV4 |
| SWITCH2 | 7 SV4 | | | | |
| VOL 2 | PUSH 9 SV4 | A 11 SV4 | B 12 SV4 | | |
| GND | 40 SV2 | 40 SV3 | 39 SV4 | 9 SV1 | |
| BACKLIGHT | 2 SV1 | | | | |
| | | | | | |
| | | | | | |
| COM1 MIC | 31 SV1 IN | 31 SV2 OUT | | | |
| COM1 | 32 SV1 IN | 32 SV2 OUT | | | |
| COM2 MIC | 29 SV1 IN | 29 SV2 OUT | | | |
| COM2 | 30 SV1 IN | 30 SV2 OUT | | | |
| COM3 MIC | 27 SV1 IN | 27 SV2 OUT | | | |
| COM3 | 28 SV1 IN | 28 SV2 OUT | | | |
| COM1/2 | 25 SV1 IN | 25 SV2 OUT | | | |
| TEL | 26 SV1 IN | 26 SV2 OUT | | | |
| PA | 23 SV1 IN | 23 SV2 OUT | | | |
| SPKR | 24 SV1 IN | 24 SV2 OUT | | | |
| MUTE | 21 SV1 IN | 21 SV2 OUT | | | |
| HI SENS | 22 SV1 IN | 22 SV2 OUT | | | |
| DME | 19 SV1 IN | 19 SV2 OUT | | | |
| NAV1 | 20 SV1 IN | 20 SV2 OUT | | | |
| ADF | 17 SV1 IN | 17 SV2 OUT | | | |
| NAV2 | 18 SV1 IN | 18 SV2 OUT | | | |
| AUX | 15 SV1 IN | 15 SV2 OUT | | | |
| MAN SQ | 13 SV1 IN | 13 SV2 OUT | | | |
| PLAY | 16 SV1 IN | 16 SV2 OUT | | | |
| PILOT | 11 SV1 IN | 3 SV2 OUT | | | |
| COPILOT | 14 SV1 IN | 14 SV2 OUT | | | |
| ENC | PUSH 6 SV3 | A 4 SV3 | B 3 SV3 | C 2 SV3 | D 1 SV3 |
| BACKUP | UP 8 SV3 | DN 5 SV3 | | | |
| GND | 39-40 SV1 | 2 SV2 | | | |