10 pin IDC
Female
2
1
10
9
10 pin IDC
Header

AUTOBRAKE	PIN
LED TRAIN GAUCHE HAUT	4
LED TRAIN GAUCHE BAS	6
LED TRAIN CENTRE HAUT	8
LED TRAIN CENTRE BAS	10
LED TRAIN DROIT HAUT	12
LED TRAIN DROIT BAS	14
BRAKE FAN PUSH	3
BRAKE FAN LED H	16
BRAKE FAN LED B	18
ANTISKID	11
AUTO LO PUSH	5
AUTO LO LED H	20
AUTO LO LED B	22
AUTO MED PUSH	7
AUTO MED LED H	24
AUTO MED LED B	26
AUTO MAX PUSH	9
AUTO MAX LED H	30

AUTO MAX LED B	**32**
TERR ON PUSH	**13**
TERR ON LED H	**34**
TERR ON LED B	**36**
BACKLIGHT	**1 + 2 -**
GND	**40-39**

CHRONO	PIN
DIS A	14
DIS B	12
DIS C	10
DIS D	8
DIS E	6
DIS F	4
DIS G	2
DIS1	16
DIS2	18
DIS3	20
DIS4	22
DIS5	24
DIS6	26
DIS7	28
DIS8	30
DIS9	32
DIS10	34
DIS11	3
DIS12	5

DIS13	**7**
DIS14	**9**
DOUBLE POINT HAUT	**36**
DOUBLE POINT CENTRE	**1**
DOUBLE POINT BAS	**38**
PUSH HAUT GAUCHE	**21**
PUSH HAUT DROIT	**11**
PUSH DATE	**23**
ENC1 DATE	**35**
ENC2 DATE	**37**
ROT HAUT POS1	**13**
ROT HAUT POS 2	**15**
ROT BAS POS 1	**17**
ROT BAS POS 2	**19**
GND	**40-39**

DCDU	PIN
BRT	3
DIM	4
MSG -	5
MSG +	6
LS1	7
LS2	8
PRINT	9
PGE -	10
PGE +	11
RS1	12
RS2	13
GND	14
BACK	1+ 2-

ILLUMINATION	PIN
KORRY PUSH	12
LED HAUT KORRY	10
LED BAS KORRY	8
ALIM POT	17
POT INFERIEUR ND	16
POT SUPERIEUR ND	9
XFR PUSH	11
POT PFD	18
POT SPEAKER	14
CONSOLE OFF	15
CONSOLE BRT	13
BACKLIGHT	1 + 2 -
GND	20-19

ISIS	PIN
BACKLIGHT	1 + 2 -
LS PUSH	3
BUGS PUSH	4
PLUS PUSH	5
MOINS PUSH	6
RST PUSH	7
BARO PUSH	8
ENC 1 BARO	9
ENC 2 BARO	10
GND	11

TERR ND	PIN
PUSH TERR	8
LED HAUT TERR	7
LED BAS TERR	5
BACKLIGHT	1 + 2 -
GND	9 & 10

GEAR	PIN
GEAR UP	1
GEAR DN	2
GND PUSH	3
GND BACKLIGHT	4
LED RED	5
BACK +	6