Electronic System Cockpit

INSTRUCTIONS FOR USE AND FIRST CONNECTION

The motherboard has an Ethernet port where you can connect an RJ45 cable to your computer port.

If you already have ESC Plug'n'Play products other than this one, you just need to add an Ethernet hub to connect them to your computer.

THANK YOU FOR FOLLOWING THIS LITTLE MANIPULATION FOR THE FIRST CONNECTION OF YOUR FIRST CARD:

IN WINDOWS:

Open settings,

Then `` Network and Internet ''

Choose Ethernet in the left tab

Then choose '' change adapter options '' in the right tab

Right click on your internet connection (icon in the task bar) and click on '' Properties ''.

Choose the line '' IPV4 '' then click on '' Properties ''

PLEASE FILL IN AS THE EXAMPLE GIVES ON THE FOLLOWING IMAGE

ONCE THIS STEP IS VALIDATED, ALL ESC PRODUCTS WILL BE AUTOMATICALLY RECOGNIZED.

IN THE CASE OF FLIGHT FACTOR A320:

Download it then extract the archive and move it all to your XPLANE 11 folder:

xplane11/aircraft/laminar/flightfactora320/plugin

YOU CAN NOW CONNECT THE RJ45 CABLE TO YOUR COMPUTER.

It is strongly recommended to power the motherboard

ONLY ONCE XPLANE 11 AND FFA320 ARE IN OPERATION.

THE MOTHERBOARD IS INITIALIZED IN APPROXIMATELY 15 SECONDS.

You are now ready to use your esc product.

Thank you for your confidence !